

1217A Parts List

<u>Ref No.</u>	<u>Part No.</u>	<u>Qty.</u>	<u>Description</u>
1	W-A121708	1	Feed Table Assembly
2	W-A121732	1	Paper Guide Assembly, Left Side
3	W-O121728	1	Paper Guide Support Shaft
4A	WRA003116	1	Retarder Roller Assembly
4B	M-S007018	1	Retarder Adjusting Knob
5	W-A121733	1	Paper Guide Assembly, Right Side
6	M-S013009	6	Roller Bearing, Bronze
7	M-S013010	2	Roller Bearing, Bronze
8	W-O121721	1	Feed Roller Shaft
9	W-A121715	1	Main Drive Roller, Long Shaft
10	M-S031035	4	Paper Stop Knob
11	M-O003125	1	Feed Roller Arbor
12	M-O003548	1	Feed Roller Rubber
13	W-O001598	1	Main Frame, Left Side
14	M-O003030	2	Nylon Guide Roller
15A	W-O001534	2	Black Paper Stop Indicator Bar
15B	M-S032007	4	Paper Stop Knob
15C	W-O001507	2	Threaded Paper Stop Clamp Bar
16	W-A121704	1	Upper (1 st) Fold Table Assembly
17	M-O001566	2	Ruler, 1 st Fold Table
18	W-A121702	1	Exit Table
19A	W-O121703	1	Conveyor Table
19B	M-S024002	3	Conveyor Belt
19C	W-O121714	1	Conveyor Drive Shaft
19D	W-O121725	1	Conveyor Idler Shaft
19E	M-S031034	2	Idler Shaft Spring
19F	W-S014005	2	Idler Shaft Bearing
19G	W-A121718	1	Stacking Wheel Assembly
20	W-O121736	1	Side Cover, Right Side
21A	M-S032009	1	Hand Knob
21B	M-S002006	1	Hand Knob Set Screw, 10-32 X 3/8"
22A	M-S045124	1	Speed Control, 110V
22A	M-S045128	1	Speed Control, 220V
22B	M-S015016	1	Speed Control Decal, Dial Plate, 110V
22C	M-S032057	1	Speed Control Knob
23	W-S022013	1	Conveyor Shaft Pulley
24	M-S023001	2	O-Ring Drive Belt
25	M-S045133	1	Fuse, 1.5Amp Slow – Blow, 110V only
25A	M-S045065	1	Fuse Holder, 110V Only
26	W-O022020	1	Timing Pulley

1217A Parts List

<u>Ref No.</u>	<u>Part No.</u>	<u>Qty.</u>	<u>Description</u>
26A	M-S002007	2	Timing Pulley Set Screw, 10-32 X 3/16" Cup Point
27	M-S025002	1	Timing Belt. 164XLO37
28	M-S022079	1	Motor Pulley
28A	M-S002004	1	Motor Pulley Set Screw #8 X 3/16" Cup Point
29	W-O001597	1	Main Frame, Right Side 110V
29	W-O121799	1	Main Frame, Right Side 220V
30	W-O121786	1	Motor Guard, 110V
30	W-O121796	1	Motor Guard, 220V
31	M-O121729	2	Tie Rod
32	M-S021047	1	Motor, 36 VDC
33	W-O121785		Chute, 110V
33	W-O121795		Chute, 220V
34	W-A121707	1	Lower (2 nd) Fold Table Assembly
35	M-O001568	2	Ruler, 2 nd Fold Table
36	W-O121787	1	Screen Cover, 110V
36	W-O121797	1	Screen Cover, 220V
37	WRA121712	2	Intermediate Fold Roller
37A	WRA121722	1	Bottom Fold Roller
38	M-O003104	3	Index Pin, Round
38A	M-O095242	1	Index Pin, Hex
39	W-I001504	1	Side Cover, Left Side
40	M-S014027	2	Bearing, Nylon (Nyliner)
41	W-O121788	1	Roller Cover, 220V Only
41A	M-S032045	2	Roller Cover Screw Cap, 220V Only
41B	M-S003082	2	Roller Cover Screw, 220V Only
42	W-O095280	1	Roller Cover Bracket, Left Side, 220V Only
42A	W-O095265	1	Roller Cover Bracket, Right Side, 220V Only
43	M-S045163	1	Circuit Breaker, .6 AMP, 220V Only
43A	M-S045065	1	Fuse Holder, 110V Only

Not Shown:

M-S045122	1	Transformer
W-A121740	1	110V AC Transformer Assembly
W-A121741	1	220V AC Transformer Assembly
M-S045123	1	Capacitor, 2200 ufd, 50V
M-S037047	1	Fan Blade
M-S045050	1	Bridge Rectifier
M-S037296	1	Power Cord, 110V Only
M-O007507	1	Feed Drive Pulley
M-O001591	1	Feed Shaft Pulley
M-S037293	1	Power Cord, 220V Only
M-S045162	1	EMI Filter, 220V Only

1217A Parts List

